POWER STATION™
GAME BOY® ADVANCE

INSTRUCTIONS FOR USE

1 For best long-term results, the Power Station battery packs must be charged for 12 to 14 hours prior to initial use. Charging overnight is recommended for subsequent charges.
2 To charge, insert the AC Adapter mini plug into the DC jack located on the Power Station .
3 Plug the AC Adapter into a wall outlet.
4 Place Battery Pack into charging receptor to begin charging back-up Battery Pack.
5 Insert the Battery Pack into the Game Boy Advance battery compartment.
6 Place Game Boy Advance with inserted Battery Pack into Power Station to charge inserted Battery Pack. Turn power OFF on Game Boy Advance prior to charging or discharging. (see below)
7 If Battery Pack begins to run out of power, replace with your back-up Battery Pack.

Charging and discharging Battery Packs:

This procedure will prolong the life of your Battery Packs.
You do not need to do this often.

1 To fully discharge your Battery Pack, place Game Boy Advance with Battery Pack installed onto Power Station .
2 Make sure the Power is turned OFF on the Game Boy Advance.
3 Press charge/discharge button located on the front of the Power Station.
4 Red light indicates the battery is charging.
5 Flashing Red light indicates you are discharging the Battery Pack. When the Battery Pack is completely discharged it will automatically begin the charging process.
6 Green Light indicates that the Battery Pack is fully charged.

CAUTION

1 Electrically Operated Product: Not recommended for children under 8 years of age. As with all electrical products, precaution should be taken to avoid electrical shock. Never dispose of batteries in a fire. It is normal for the battery charger and/or adapter to become slightly warm during charging.
2 Do not attempt to disassemble or make repairs.
3 Do not submerge in water.
4 Unplug the AC Adapter when not in use.